

Einstein Telescope site characterisation measures and their impact on the third generation GW detectors



Seismic data analysis exercitations

In the lecture we will see two ways to access and analyse the seismic data:

- 1. Accessing stored *seed* files with MatLab functions;
- 2. Using the ObsPy environment under Python to access data directly from seismic stations in the network.

Requirements:

- (1) Having MatLab installed on your laptop
- (2) Having ObsPy installed on your laptop (see next pages)

A complete guide about obspy is available here: https://docs.obspy.org/

A tutorial is available here: obspy: https://docs.obspy.org/tutorial

A general installation guide of obspy under Anaconda is available here: https://www.geophysik.uni-muenchen.de/https://www.geophysik.uni-muenchen.de/https://www.geophysik.uni-megies/installation2.pdf

The installation guide under linux systems is available here: https://github.com/obspy/obspy/wiki/Installation-on-Linux-via-Apt-Repository

Below you can find a guide to install everything is needed for the proposed exercitations with Anaconda:

- 1) install anaconda from https://www.anaconda.com/products/individual
- 2) now add conda forge channel:

\$ conda config --add channels conda-forge

3) setup a separate environment for obspy:

\$ conda create -n obspy python=3.8

\$ conda activate obspy

4) Install pre-compiled ObsPy conda package from Anaconda cloud with:

\$ conda install obspy

and check for updates:

\$ conda update obspy

5) install Jupyter Notebook from Anaconda Navigator interface under Obspy environment

\$ jupyter notebook

here click on new, python 3

6) from anaconda navigator, select obspy, open terminal, and then type Jupyter notebook. The notebook will run in your browser, you will find the local directories and existing notebooks (ipynb) in http://localhost:8888/tree.

if kernel error appears in Jupyter Notebook edit the kernel.json file in

\anaconda\envs\obspy\share\jupyter\kernels\python3\

and modify the path to python executable (e.g. \anaconda/envs/obspy/bin/python in \anaconda/envs/obspy/python using ObsPy with local stored data requires to have the data placed respecting the SDS scheme: year/network/station_name/channel_name, with channel names like HHZ.D, EHZ.D... e.g.: 2020/ET/SOE0/HHZ.D . root is the variable indicating the "year" (local) path.

a working directory for the data can be created through the notebook interface. Under Windows OS, you can find it (or create it) under your user directory (C:\\Users\\user_name\)

- 7) install the following packages:
- install matplot lib
 - \$ python -m pip install -U pip
 - \$ python -m pip install -U matplotlib
- install numpy:
 - \$ conda install numpy
- install basemap:
 - \$ conda install basemap
- install pandas
 - \$ conda install pandas
- install xarray:
 - \$ conda install -c conda-forge xarray dask netCDF4 bottleneck